















FAST MOVING Parts Guide

AYP (CONT.)

	STENS NO.	OEM NO.	DESCRIPTION/FITS MODELS
	340-170	131322	BLADE 19 3/16" L; 5/8" star center hole
	340-178	138971/ 138498	BLADE 21 1/16" L; 5/8" star center hole
	340-218	204340218/ 752233	MULCHING BLADE 20" L; 5/8" center hole
	340-222	180054/ 173920	HI-LIFT BLADE 16 11/16" L; 5 point star center hole
	340-256	204335256/ 752234	MULCHING BLADE 21 11/16" L; 5/8" center hole
	340-440	134149	SAND BLADE 21" L; 5/8" star center hole
	405-221	851514	BLADE ADAPTER Fits AYP, Husqvarna
	405-435	850977	BLADE ADAPTER Fits AYP and Husqvarna
	430-538	STD365402	STARTER SWITCH Magneto type; 3 positions; 5 terminals
	430-674	140301	STARTER SWITCH Magneto type; 4 positions; 7 terminals
	435-065	110832X	STARTER SOLENOID 3 pole style; 12 volt; 1/4"-20 studs
	435-099	146154	STARTER SOLENOID 4 pole style; 12 volt; 5/16"-24 studs