

Toro Groundsmaster 4700



PART NO.	DESCRIPTION	REPLACES
1. 102-073	Air Filter	Toro 108-3814
2. 102-305	Air Filter	Toro 108-3810
3. 102-077	Inner Air Filter	Toro 108-3816
4. 230-060	Bearing	Toro 38-7820
5. 230-969	Bearing	Toro 108-9017
6. 230-961	Bearing	Toro 251-347
7. 120-678	Fuel Filter	Toro 98-7612
8. 120-562	Fuel Filter	Toro 108-3854
9. 120-566	Fuel Filter Shop Pack (case of 25)	Toro 108-3854
10. 302-627	Silver Streak Toothed Blade	Toro 107-0235-03
11. 355-100	Medium-Lift Blade	Toro 104-5183
12. 345-190	Combination Blade	Toro 108-9026-03
13. 120-360	Oil Filter	Toro 42-9030
14. 120-818	Transmission Filter	Toro 54-0110
15. 120-519	Transmission Filter	Toro 23-2300
16. 120-710	Transmission Filter	Toro 86-3010
17. 165-524	Carlisle Tire (26x12.00-12)	Toro 99-5434