

Toro Workman 1110



PART NO.	DESCRIPTION	REPLACES
1. 100-465	Air Filter	Toro 108-3808
2. 100-541	Inner Air Filter	Toro 98-2982
3. 100-533	Air Filter	Toro 108-3811
4. 230-060	Bearing	Toro 38-7820
5. 230-102	Bearing	Toro 116-0720
6. 215-285	Tapered Bearing Set	Toro 27-0960
7. 215-103	Tapered Roller Bearing	Toro 254-94
8. 215-111	Bearing Race	Toro 1-543508
9. 120-444	Fuel Filter	Toro 108-3831
10. 120-678	Fuel Filter	Toro 98-7612
11. 120-914	Fuel Filter	Toro 94-2690
12. 120-410	Fuel Filter	Toro 108-3831
13. 175-505	Valve Stem #412	Toro 5108