

Toro Workman 3000, 3100, 3120, 3200, 3420, 4200 and 4300D



PART NO.	DESCRIPTION	REPLACES
1. 100-465	Air Filter	Toro 108-3808
2. 100-541	Inner Air Filter	Toro 98-2982
3. 100-533	Air Filter	Toro 108-3811
4. 230-102	Bearing	Toro 116-0720
5. 215-285	Tapered Bearing Set	Toro 27-0960
6. 215-103	Tapered Roller Bearing	Toro 254-94
7. 215-111	Bearing Race	Toro 1-543508
8. 120-562	Fuel Filter	Toro 108-3854
9. 120-566	Fuel Filter Shop Pack (case of 25)	Toro 108-3854
10. 120-570	Fuel Filter Merchandiser	Toro 108-3854
11. 120-444	Fuel Filter	Toro 108-3831
12. 120-678	Fuel Filter	Toro 98-7612
13. 120-410	Fuel Filter	Toro 108-3831
14. 120-634	Oil Filter	Toro 120-4276
15. 120-990	Oil Filter Shop Pack (case of 12)	Toro 108-3842
16. 120-360	Oil Filter (diesel only)	Toro 108-3841
17. 120-818	Transmission Filter	Toro 54-0110
18. 175-505	Valve Stem #412	Toro 5108